



Product Code . ILS-ELE-10624

Common Rail Pump With Injector

Description

Aspiration of the fuel from the interior of the pump via a flat valve. Discharge of the pressurized fuel via a ball valve into the collector line to the rail. High pressure pump by turning the eccentric cam the operation of the pump piston can be seen.

Injector: Injection nozzle, solenoid valve for volume control and for control of start of delivery.

Indian Lab Suppliers,

Direct Contact Details ☎ +91-8569909696 ✉ sales@indianlabsuppliers.com
💻 www.indianlabsuppliers.com